
Sonos Ace Ultra



Overview

Sonos Ace Ultra is everything you want in your headphones. And then some.

- **Every note, just right.** Sonos-designed driver delivers deep bass, clear detail, and balanced sound you can count on. Adjust it with EQ controls from around the world and Sound Check for personalized tuning.
- **Tune it to your ears.** Up to 3x more Active Noise Cancellation than Sonos Ace. In-ear seals ensure you can hear the music.
- **Battery that actually lasts.** Up to 30 hours with headphones and up to 8 hours on a single charge. Add Active Noise Cancellation off.
- **Part of the Sonos system.** Play music, TV, your local library, even what's for dinner.And when you're ready for more wireless or surround sound, it's all connected.
- **Comfort you wouldn't trust** with a phone, making call quality clear and an adjustable headband create a custom fit.

Controls, lights, and ports

1	**Control Key**	**Playback** • Play/Pause: Press once to pause or resume streaming content • Next: Double-press • Previous: Triple-press • Skip ahead: Swipe up or down. Slide and hold to quickly change the volume **Calls** • While you are using headphones to take a call, press and hold to swap audio with nearby compatible speakers
2	**Noise Control/Voice Control**	**Noise Control** Press to switch between Active Noise Cancellation and Aware Mode. **Note:** In the Sonos app, you can change which Noise Control options the button provides. **Voice Control** Press and hold to activate your phone's voice assistant, such as Siri or Alexa. Tap to choose which the button to listen
3	**Status light**	Indicates headphone charging status. Results are connection, and paired product updates and errors. It's one of two when you're leaving the app.
4	**Power Bluetooth**	**Power on/off** • Press and hold when you're headphones have been docked more. **Note:** Sonos Ace Ultra is intermediately ready to pair with a Bluetooth device when powered on after a factory reset.
5	**USB-C port**	**Charging** Use the included cable to connect a USB-C wall box or USB-compliant USB-C power supply. 7.5 W minimum required. **Line-in** You can play your headphones with an audio device that uses: • USB-C to 3.5 mm cable included. Used for in-flight entertainment and devices without Bluetooth. Connect to the USB-C port on the left headphone. • USB-C to USB-C cable included. Used for audio playback on devices that support USB-C audio. Connect to the USB-C port on the left headphone.

Adjust the fit

Sonos Ace Ultra combines advanced sensors, ear seals, and a comfortable headband for different head shapes. Here's how to get the most out of your headphones' fit, comfort, and sound.

Your headphones automatically personalize sound based on how you're inside the ear cup, an interactive experience tailored to your unique head shape and ear canals so everyone can enjoy rich sound.

- If you're using the Sonos app, follow the instructions to complete the fit test.
- If you're using Sonos on a tablet and can't set up a fit test, you can still adjust the headband to find the right fit of the ear cup, and then tap the Check fit button in the app. Then take a call or something to hear how it sounds, and tap Check fit again to finish the fit test.
- To re-run a Sonos fit test, open the Sonos app, select your headphones, and then tap the Settings icon. Choose Check the fit of the headband as needed by pulling the ear cups in opening the ear cups.

Ear cushion replacement

Ear cushions can be easily replaced if they wear out over time. Each cushion is securely held in place by magnets and can be removed with a gentle pull.

Before installing new ear cushions, clean your Sonos Ace Ultra headphones with a soft, dry cloth.

- Make sure both cushions are on the correct sides. Look for the L and R on the inside.
- Before aligning a cushion with the ear cup, look for the arrow on the cushion to make sure the front of each cushion is correctly oriented.
- Gently press the cushions and eventually snaps into place.

Bluetooth pairing

Sonos Ace Ultra connects to your mobile device via Bluetooth device when activated or after a factory reset.

To connect your Sonos Ace Ultra to a new device, make sure Bluetooth is enabled on the device you want to use. Then, put your headphones in pairing mode by pressing and holding the Power Bluetooth button on the left ear cup. Your headphones will enter pairing mode automatically for up to 5 minutes after they're powered on. Select Sonos Ace Ultra from the list of available Bluetooth devices.

If you're pairing while streaming from a Mac, hold the Mute switch for a brief second to avoid unwanted sounds or interruptions.

If you're pairing while Sonos Ace Ultra is off, you have 1 minute before it will enter pairing mode.

To connect to a device you've already paired with, put your headphones in pairing mode, then select Sonos Ace Ultra from the list of available Bluetooth devices.

- If you're connecting while streaming Sonos Ace Ultra, you'll hear a sound confirming that your Sonos Ace Ultra is connected.
- Once connected, the device will pair to Sonos Ace Ultra with change to continue and your device Bluetooth settings will show your headphones as connected.

Light	Description
Solid white	Powered on, and connected to a Bluetooth device
Solid blue	Powered on, connected to a device via Bluetooth
Blinking blue	Powered on, searching for a Bluetooth device

Multipoint

Multipoint lets you pair Sonos Ace Ultra's Bluetooth devices and automatically switch between audio sources. You can have Bluetooth connected to both of your devices.

To set up Multipoint:

1. Go to **Settings** ⚙.
2. Choose Sonos Ace Ultra under **Headphones**.
3. Under **Bluetooth**, then select **Multipoint**.
4. Under **Multipoint** on the device. Sonos Ace Ultra Settings

Power and charging

Use the included cable to connect a USB-C® wall box or USB-compliant USB-C power supply. 7.5 W minimum required. Charging time is 2 hours.

While your Sonos Ace Ultra is charging, you can continue to listen to music or watch TV.

Note: Charge your Sonos Ace Ultra at an ambient temperature between 41° and 104°F (5° to 40°C).

Low battery

When your battery level reaches 15% power, you'll hear a voice and the status light will flash orange.

Light	Description
Flashing orange	Between 5% and 15% battery remaining

Charging

Use the included cable to connect Sonos Ace Ultra to power.

- The battery light will show **solid orange** when your headphones are plugged in and charging.
- The status light will show **solid green** when your headphones are plugged in and have a full charge.

Light	Description
Solid orange	Plugged in and charging normally. Below 100% charge
Solid green	100% battery. You can unplug your headphones
Flashing red	Charging error. Unplug your headphones from power

Rapid charging

When your Sonos Ace Ultra battery is 10% power or more, rapid charging quickly recharges them to give you 3 hours of playback in just 3 minutes.

Use the included USB-C to USB-C cable and a compliant USB-C power supply and included to charge your headphones.

- 3 hours of playback in 3 minutes
- 10 hours of playback in 10 minutes

Note: Rapid charging requires an ambient temperature between 59°F and 95°F (15°C to 35°C). Outside this range, your Sonos Ace Ultra charges at standard speed.

Linking to your system

You can link Sonos Ace Ultra to your system and then use the Sonos app to play content to them. You can also connect them to a TV and control the volume of your system with the TV remote. TV can be set to Sonos, or line. To use headphones, TV must be connected to your system.

Sonos Ace Ultra can be linked to a Sonos system that includes Sonos Arc Ultra, Arc, Arc Gen 1, Beam (Gen 2), or Ray. With one device in the system, Sonos Ace Ultra can be set directly as an SMS and HDMI-ARC-enabled home entertaining. Sonos Ace Ultra can be linked to a Sonos system that includes Sonos Arc Ultra, Arc, Arc Gen 1, Beam (Gen 2), or Ray. With one device in the system, Sonos Ace Ultra can be set directly as an SMS and HDMI-ARC-enabled home entertaining.

Note: Turn down all Sonos Ace Ultra volume on the TV. Audio from your TV will be heard from your Sonos Ace Ultra and not from the TV speakers.

Note: Sonos Ace Ultra can be linked to a Sonos system that includes Sonos Arc Ultra, Arc, Arc Gen 1, Beam (Gen 2), or Ray. With one device in the system, Sonos Ace Ultra can be set directly as an SMS and HDMI-ARC-enabled home entertaining. Sonos Ace Ultra can be linked to a Sonos system that includes Sonos Arc Ultra, Arc, Arc Gen 1, Beam (Gen 2), or Ray. With one device in the system, Sonos Ace Ultra can be set directly as an SMS and HDMI-ARC-enabled home entertaining.

TV Audio Swap

TV Audio Swap allows you to move TV audio from a compatible Sonos soundbar to Sonos Ace Ultra. Set it up and it runs in the background whenever you're watching TV.

Once it's set up, press and hold the Control Key on your right ear cup to switch to your headphones in seconds. Press and hold the Control Key again to switch back to your soundbar. Sonos Ace Ultra remembers the last volume level for each device, so you don't have to adjust it.

Audio quality and dynamic head tracking for the most immersive experience available.

Voice control

If your Sonos Ace Ultra is connected to a Bluetooth device that has a built-in voice assistant, you can activate it by pressing and holding the Control Key on the left ear cup. Refer to your device's documentation for more information.

Wear detection

Sonos Ace Ultra senses when it's in the user's ear to detect if you're wearing them. When you take them off, Sonos Ace Ultra pauses playback and lowers the volume.

Wear detection is turned on by default. With wear detection on, Sonos Ace Ultra will pause when it's off. To turn off wear detection, open the Sonos app, select your headphones, and then tap Settings and turn off Wear detection.

Note: Turn down all Sonos Ace Ultra volume on the TV. Audio from your TV will be heard from your Sonos Ace Ultra and not from the TV speakers.

Phone calls

Sonos Ace Ultra's built-in microphones and beamforming technology combine clear audio during phone calls.

Answer a call

Press the Control Key once to answer an incoming call. You'll hear a tone when the call connects successfully.

Note: If you want to make a call on your headphones to someone in your contacts, you'll need to use your phone's voice assistant. Refer to your device's documentation for more information.

End a call

Press the Control Key once to end an active call. You'll hear a tone when the call ends.

Product settings

Use the Sonos app to adjust settings for Sonos Ace Ultra.

1. Go to **Settings** ⚙.
2. Choose Sonos Ace Ultra under **Headphones**.

Settings	Description
Name	Change the name of your Sonos Ace Ultra. This name will show up in Bluetooth device settings and the Sonos app.
Status	Displays battery percentage and firmware version.
Noise Control	My controls: Choose of Noise Control • Active Noise Cancellation: Significantly reduces background noise. Make sure Sonos Ace Ultra fits the ear snugly to get the most out of this mode. • Aware Mode: Sonos Ace Ultra uses its microphones to let in more sound. Aware mode is also very handy when your surroundings without removing your headphones. • Off Sound Check: Tune your headphones to your hearing. Sound Check plays a series of tones to personalize sound and audio balance. Sonos Ace Ultra will remember your Sound Check settings for each user. Additional settings are also available in the Sonos app. • Sound Check: Personalize the audio for your hearing. • Reset Sound Check: Restore the factory EQ settings. • Balance: Adjust the balance between the left and right ear cups. • Sound Check: Increase the clarity of voices and put any audio you're in Aware Mode.
EQ	Voice enhancement in the EQ: • Bass • Treble • Balance • Loudness Custom Fixed Tuning (on or off)
Head Tracking	Turn on or off to use Sonos Intelligent Motion Processing with Dolby Head Tracking while listening to music. This feature is available on Windows devices. Head tracking requires surround audio on Spatial Audio sound with different channels of sound to create a more immersive experience. Learn more about Dolby Head Tracking.
System	• **Spatial Audio:** Head Fit Check: Sonos. Turn on or off when compact Sonos Ace Ultra to your system. Learn more about Sonos Spatial Audio. • **Head tracking:** Head Fit Check: Sonos. Turn on or off when compact Sonos Ace Ultra to your system. Learn more about Sonos Spatial Audio. • **Audio Swap:** Turn on or off when compact Sonos Ace Ultra to your system. Learn more about Sonos Spatial Audio. Note: Not available when Setting Audio™ type of headphones.
Bluetooth	Manage multipoint, unregistered connected devices, and add or remove connections to various Bluetooth devices.
Battery	• **Charging:** Change how you use headphones charge with rapid charging. • **Power Saving:** Change how your headphones save battery with power saving. Choose how long before your headphones turn off.
Hardware Controls	• **Voice Control:** Select the button you want to cycle through when pressing and holding the Control Key. • **Wear Detection:** Turn on or off playback control and sensor when you are not in your headphones.
About	• Find product name and model. • Check for software updates and see the current software version.

Specifications

Audio

Drivers	Custom-designed 40 mm dynamic driver in each ear cup
Microphones	10 microphones for noise control and voice targeting
Spatial audio	Stream spatial audio content from supported services and devices
Location audio	Enjoy immersive audio over Bluetooth with a mobile device that supports spatial audio, such as a select iOS device
Noise control	Sonos Active Cancellation blocks external sounds. Aware mode lowers ambient sound while you're listening
Head tracking	Sonos-designed Motion Processing with Dolby Head Tracking. Enable this feature in the Sonos app
TV Audio Swap	Press the Control Key to swap sound from a compatible Sonos soundbar to Sonos Ace Ultra and back. Requires TV connection
Dolby Atmos	Requires a compatible device and a streaming content
Adjustable EQ	Set the Sonos app to adjust bass, treble, and balance

Details & Dimensions

Dimensions	• **Height:** 7.48 in (190 mm) • **Width:** 6.85 in (174 mm) • **Depth:** 3.11 in (80 mm)
Weight	0.73 lbs (331 g)
Colors	• Black • Soft White • Sapphi • Sand
Finish	• Matte • Stainless steel • Hyper-leather
Lids	Light on the bottom of the left ear cup indicates connection status

Controls

Control Key	• **Slide up and down** to adjust volume • **Press once** to play/pause • **Press twice** to skip ahead • **Press three times** to play previous track • **Press once** to answer a call • **Press and hold** to decline a call
Noise Control/Voice (right ear cup)	• Press to switch between Active Noise Cancellation and Aware Mode (or other Noise Control options you've selected in the Sonos app) • Press and hold to activate the voice assistant
Power/Bluetooth (left ear cup)	• Press and hold the Power/Bluetooth button when 2 seconds to pair your headphones to a Bluetooth device • Press and hold the Power/Bluetooth button when 7 seconds to turn your headphones into Bluetooth pairing mode and activate a new device

Power & Connectivity

Bluetooth	Bluetooth 5.3 supports app streaming from any Bluetooth-enabled device
Battery (rechargeable)	Up to 30 hours of playback on a single charge **Important:** Don't use with your hands or mounting company to determine the proper charging and battery life.
Charging	Use the included cable to connect an USB-C® wall box or USB-compliant USB-C power supply. 7.5 W minimum required. Rapid charge provides 3 hours of playback in just 3 minutes with Pro, Full charge in 10 minutes with Pro, Full charge in 10 minutes **Note:** The power adapter must supply an at least 5 Watts output for 3 minutes to use the maximum charging speed.
Ports	• Supports USB-C® charging and USB-C audio • Use the audio cord from the app and ready with compatible speakers
Operating temperature	32°F to 104°F (0°C to 40°C)
Charging temperature	41°F to 104°F (5°C to 40°C)
Rapid charging temperature	59°F to 95°F (15°C to 35°C)

What's in the box?

Product	Sonos Ace Ultra
Quick start	Sonos Ace Ultra with setup guide
USB-C to USB-C cable	1.5 ft (0.5 m)
USB-C to 3.5 mm cable	3.28 ft (1 m) **Note:** Sonos Ace Ultra is not compatible with third-party cables.
Documentation	Quickstart Guide and legal/warranty information

Requirements

Audio source	Supported Bluetooth devices such as a smartphone
Power source	Use the included cable to connect a USB-C® wall box or USB-compliant USB-C power supply. 7.5 W minimum required.

Important safety information

- Read these instructions. Keep these instructions. Heed all warnings. Follow all instructions.
- Clean only with dry cloth. Do not use liquid cleaners or aerosol cleaners. Unplug this product from the wall outlet before cleaning.
- Keep away from fire and heat sources such as radiators, heat registers, stoves, or other apparatus that produce heat.
- Do not block any ventilation openings. Install in accordance with the manufacturer's instructions.
- Do not install near any heat sources such as radiators, heat registers, stoves, or other apparatus (including amplifiers) that produce heat.
- Only use attachments/accessories specified by the manufacturer, such as the wall mount recommended by Sonos. Use only with the cart, stand, tripod, bracket, or table specified by the manufacturer, or sold with the apparatus. When a cart is used, use caution when moving the cart/apparatus combination to avoid injury from tip-over.
- Unplug this apparatus during lightning storms or when unused for long periods of time.
- Refer all servicing to qualified service personnel. Servicing is required when the apparatus has been damaged in any way, such as power-supply cord or plug is damaged, liquid has been spilled or objects have fallen into the apparatus, the apparatus has been exposed to rain or moisture, does not operate normally, or has been dropped.
- Do not expose this apparatus to dripping or splashing and ensure that no objects filled with liquids, such as vases, are placed on the apparatus.
- To turn off the apparatus completely, disconnect it from the power supply. Disconnect the power supply from the wall plug or the back of the unit. This should be done if the apparatus is not used for a long period of time.
- Do not overload wall outlets, extension cords, or integrated convenience receptacles as this can result in a risk of fire or electric shock.
- Do not operate the apparatus in the presence of flammable or explosive materials.
- Caution should be taken when using earbuds, headphones, or headsets with this product as excessive sound pressure from earbuds, headphones, or headsets can cause hearing loss.
- Do not attempt to service the apparatus. Opening or removing covers may expose you to dangerous voltage or other hazards.
- Refer all servicing to Sonos qualified service personnel.
- Warning: The unit is not waterproof. To reduce the risk of fire or electric shock, do not expose this product to rain or moisture. Do not place objects filled with liquids on the unit.
- Do not use this product while cycling, driving, or engaged in any other activity where your full attention is required. Doing so may result in an accident.